



OVEN & GRILL CLEANER NON CAUSTIC

Highly active and Safe Oven Cleaner

FEATURES	AREAS OF USE
<ul style="list-style-type: none">• Non Caustic• Safe on Aluminium• Safe on Stainless steel• Safe on Oven Seals• Breaks Down Fats, Oil and Grease• Safe on Painted Surfaces	<ul style="list-style-type: none">• Conventional Ovens• Oven/ Rotisseries• Hot Plates• Petrol Display Tanks• BBQ Areas• Fryer Hoods• Deep Fryers

Description

Oven & Grill Cleaner Non Caustic is suitable for all types of modern ovens. This market leading product removes all types of soiling such as, fat, greases, and oil residue from oven, rotisseries, hot plates, hoods and deep fryers. Its low hazard formulation reduces risk in use.

Directions For Use

Oven & Grill Cleaner Non Caustic: Squirt onto surfaces neat or apply using a wet sponge. Do not use a scouring pad (unless rated non scratch). Leave for 10-20 minutes depending on the degree of soiling. Agitate and rinse clean with water. If required neutralise with vinegar, rinse thoroughly with water. Dry with paper towel.

Safety Information

Oven & Grill Cleaner Non Caustic is classified as an irritant, contact of the concentrate with the skin and eyes should be avoided.

If poisoning occurs contact a doctor or Poisons Information Centre, Australia on 13 11 26. If in eyes, hold open and flood with plenty of clean water – seek medical advice if necessary. If swallowed do not induce vomiting, give water to drink and seek medical attention. If skin contact occurs wash area thoroughly with clean water.

Packaging - 5lt

PFD ORDER CODE:
047994